



NOTE:
J410: DC375
P411: DC37P
J412: DB25S
P413: DC37P

◇ * * - ON PAGE SIGNAL (FROM/TO THIS PAGE ONLY)

NOTE: REMOVE JUMPERS JP1 THRU JP4

